


TOYOTA AD331L & AD332L (LP)



TOYOTA AD331L & AD332L (LP)

NO.	PARTS NAME	NO.	PARTS NAME	NO.	PARTS NAME	NO.	PARTS NAME
1	ARM BED	82	PRESSER BAR GUIDE	175	SPRING FOR 174	254	FLAT WASHER FOR 253
2	RUBBER PLUG FOR 110	83	SET SCREW FOR 82	176	CLUTCH BEARING	255	NUT FOR 256
3	SPRING PIN FOR 18	84	PRESSER BAR GUIDE BRACKET	177	TENSION ADJUSTING PULLEY SHAFT	256	HINGE NUT FOR 253
4	RUBBER PLUG FOR 229	85	SET SCREW FOR 84	177-1	TENSION ADJUSTING PULLEY	257	NEEDLE FEED DRIVE ROD
5	TOP COVER PLATE	86	WALKING FOOT BAR	177-2	STOP RING FOR 177-1	258	HINGE SCREW FOR 257
6	GASKET FOR 5	87	WALKING FOOT BAR SPRING	177-3	STOP RING FOR 177	259	NUT FOR 258
7	OIL GAUGE FOR 5	88	BRACKET FOR 89	179	SET SCREW FOR 177	260	NEEDLE FEED DRIVE ARM
8	THREAD GUIDE WITH THREE HOLES	89	GUIDE BAR FOR 87	180	OIL CAP SCREW FOR 184	261	SET SCREW FOR 260
9	NUT FOR 8	90	OIL FELT FOR 86	181	LOWER SHAFT	262	FRONT BUSHING FOR 60
10	SPRING PIN FOR 11	91	SET SCREW FOR 88	182	LOWER SHAFT FRONT BUSHING	263	REAR BUSHING FOR 60
11	OIL ADJUSTING PUSH BUTTON	92	HINGE SCREW FOR 93	183	LOWER SHAFT CENTER BUSHING	264	SET SCREW FOR 263
12	OIL WICK RETAINER	93	KNEE LIFTER LEVER	184	OIL FELT FOR 182	265	FEED DOG
13	OIL WICK RETAINER	94A	ADJUST PLATE FOR TENSION RELEASE	185	OIL FELT FOR 181 & 182	266	FEED BAR
14	SET SCREW FOR 12 & 13	94B	SUPPORT FOR 94A	186	SET SCREW FOR 186	267	FEED BAR SHAFT
15	SET SCREW FOR 5	94C	FLAT WASHER FOR 94D	187	FEED CAM	268	FEED FORK
17	SET SCREW FOR 344	94D	SET SCREW FOR 94A	188	SET SCREW FOR 186	269	OIL FELT FOR 268
18	FACE COVER PLATE	95	SET SCREW FOR 94 B	188	NEEDLE BEARING FOR 186	270	SPRING WASHER FOR 271
19	SET SCREW FOR 18	96	SPRING FOR 93	189	BEARING GUIDE FOR 188	271	SET SCREW FOR 268
20	STOP RING FOR 21	97	PRESSER SPRING	190	SET SCREW FOR 189	272	SET SCREW FOR 269
21	PUSH BUTTON	98	HINGE SCREW FOR 97	191	FEED REGULATOR BODY	273	FEED LIFTING CAM
22	SPRING FOR 21	99	PRESSER BAR LIFTER LEVER	192	SET SCREW FOR 191	274	SET SCREW FOR 273
23	SET SCREW FOR 25	100	HINGE FOR 99	193	SET SCREW FOR 203	275	FEED CAM UPPER
24	NEEDLE BAR ONLY	102	PRESSER SPRING SUPPORT	194	FEED ROD	276	SET SCREW FOR 275
25	THREAD GUIDE FOR 24	103	SET SCREW FOR 102	195	SET SCREW FOR 200	277	UPPER FEED BAR ARM
26	SET SCREW FOR 27	108	BEARING COLLAR FOR 180	196	HINGE SHAFT FOR 199	278	SET SCREW FOR 277
27	NEEDLE # 23	109	SET SCREW FOR 108 & 110	197	FEED ROCK ARM	279	UPPER FEED CONNECTING ROD
29	HINGE STUD FOR 343	110	BEARING COLLAR FOR 111	198	SET SCREW FOR 197	280	HINGE SCREW FOR 279
30	SLIDING GUIDE FOR 343	111	TOP SHAFT ONLY	199	FEED LINK A	281	NUT FOR 280
31	OIL FELT FOR 30	112	PACKING FOR 115	200	HINGE PIN FOR 194	282	FLAT WASHER FOR 280
32	NEEDLE BAR CRANK ROD	113	SET SCREW FOR 114	201	NEEDLE BEARING FOR 200	283	BUSHING FOR 279
33	NEEDLE BAR BRACKET COMPLETE	114	OIL FELT FOR 111	202	FEED LINK B	284	FEED LINK UPPER
34	SLIDING BLOCK FOR 33	115	OIL STOPPER SCREW	203	HINGE PIN FOR 202	285	UPPER FEED SHAFT BUSHING
35	SET SCREW FOR 33	116	BEARING COMPLETE	204	HINGE PIN FOR 191	287	UPPER FEED SHAFT
36	OIL FELT FOR 33	117	SET SCREW FOR 118	205	SET SCREW FOR 204	288	HINGE SCREW FOR 284
37	TAKE UP LEVER CRANK	118	COLLAR FOR 111	206	SPRING PIN FOR 208	289	NUT FOR 288
37-1	SET SCREW FOR 37	119	HAND WHEEL	207	FEED ROCK SHAFT	290	PRESSER BAR BRACKET
37-2	SET SCREW FOR 38	120	SET SCREW FOR 119	208	FEED ROCK ARM REAR	291	SET SCREW FOR 290
37-3	SET SCREW FOR 38	121	CAP SCREW FOR 119	209	SET SCREW FOR 210	292	PIVOT SCREW FOR 290
38	HINGE PIN FOR 32	122	TIMING BELT	210	COLLAR FOR 207	293	ROLLER FOR 292
39	OIL FELT FOR 38	123	SET SCREW FOR 124	211	FEED ROCK SHAFT FRONT BUSHING	294	FEED LINK SUPPORT
40	OIL STOPPER PLATE	124	COLLAR FOR 180	212	FEED ROCK SHAFT CENTER BUSHING	295	FEED LINK LOWER
41	SET SCREW FOR 40	129	FLAT WASHER FOR 130	213	FEED ROCK SHAFT REAR BUSHING	297	HINGE SCREW FOR 298
42	SET SCREW FOR 296	130	SET SCREW FOR 345	214	SET SCREW FOR 211 & 213	298	KNEE LIFTER LEVER B
43	THREAD GUIDE CENTER	131	HINGE PIN FOR 137	215	FEED CONTROL SHAFT FRONT BUSHING	299	HINGE SCREW FOR 303
44	SET SCREW FOR 43	132	OIL FELT FOR 131	216	FEED CONTROL SHAFT REAR BUSHING	300	FLAT WASHER FOR 304
45	THREAD GUIDE LOWER	133	NUT FOR 131	217	SET SCREW FOR 215 & 216	301	SPRING ADJUST COLLAR FOR 305
46	SET SCREW FOR 45	134	HINGE PIN FOR 346	218	SET SCREW FOR 219	302	ROLLER BRACKET
47	THREAD GUIDE UPPER	135	OIL FELT FOR 134	219	SPRING ADJUST COLLAR	303	ROLLER FOR 302
48	SET SCREW FOR 47	136	SET SCREW FOR 134	220	FEED CONTROL SHAFT	304	KNEE LIFTER HULL ROD
49	TENSION COMPLETE	139	OIL GAUGE GUIDE	221	SPRING FOR 220	305	SPRING FOR 304
50	CHECK SPRING	142	SET SCREW FOR 348&349	222	FEED REGULATOR ARM	306	SET SCREW FOR 302
51	SET SCREW FOR 49	143	OIL GAUGE	223	SET SCREW FOR 222	307	STOPPER PIN FOR 304
52	STOPPER FOR 67	144	OIL REGULATING SCREW	224	SET SCREW FOR 222	308	STITCH LENGTH INDICATOR PLATE
53	SET SCREW FOR 52	145	NUT FOR 144	225	FEED REGULATOR ROD	309	FEED CAM COMPLETE
54	OIL WICK RETAINER FOR 56	146	FLAT WASHER FOR 148	226	HINGE SCREW FOR 232	310	SET SCREW FOR 309
55	FLAT WASHER FOR 60	147	SPRING WASHER FOR 148	227	HINGE SCREW FOR 225	311	SET SCREW FOR 309
56	NEEDLE BAR ARM	148	SET SCREW FOR 341	228	STOP RING FOR 229	312	FEED ROCK ARM
57	GUIDE PLATE FOR 34	149	SET SCREW FOR 342	229	HINGE PIN FOR 232	313	FEED ROD
58	PIN FOR 56	151	GASKET FOR 341	230	SET SCREW FOR 229	315	GUIDE BLOCK FOR 293
59	SET SCREW FOR 57	152	SET SCREW FOR 154	231	HAND LEVER FOR FEED REGULATOR	316	GUIDE BLOCK BASE
60	NEEDLE FEED ROCK SHAFT	153	SET SCREW FOR 154	232	HAND LEVER ARM FOR FEED REGULATOR	317	SET SCREW FOR 316
61	GUIDE PLATE FOR 56	154	LOWER SHAFT GEAR	233	STOP PIN FOR 237	318	SET SCREW FOR 315
62	SPACER FOR 61	155	SET SCREW FOR 157	234	SPRING FOR 233	319	TUBE RETAINER
63	SET SCREW FOR 61	156	SET SCREW FOR 157	235	FEED REGULATOR DIAL BASE	320	SET SCREW FOR 319
64	NUT FOR 63	157	HOOK SHAFT GEAR	236	SET SCREW FOR 231	321	OIL TUBE
65	HOLDER FOR OIL WICK	158	PINCH SLEEVE LOWER	237	FEED REGULATOR DIAL	322	OIL WICK
66	SLIDE PLATE LEFT	159	PINCH SLEEVE UPPER	238	SET SCREW FOR 239	323	ACCESSORY BOX
67	SLIDE PLATE RIGHT	160	SET SCREW FOR 159	239	STITCH LENGTH INDICATOR	326	NAIL
68	STOPPER PIN FOR 67	161	FLAT WASHER FOR 111	240	SET SCREW FOR 241	327	NEEDLE
69	SPRING FOR 68	162	TOP SHAFT BUSHING	241	FEED REGULATOR PLATE	328	DRIVER MIDDLE
70	PRESSER BAR ONLY	163	OIL FELT FOR 162	242	FEED STOPPER REAR BLOCK	329	DRIVER SMALL
71	WALKING FOOT COMPLETE	164	OIL FELT FOR 162	243	FEED STOPPER FRONT BLOCK	330	WRENCH SMALL
72	PRESSURE REGULATOR SCREW	165	SET SCREW FOR 162	244	SET SCREW FOR 242	331	WRENCH LARGE
73	TENSION RELEASE PIN	166	SPRING RETAINER SCREW	245	LATCHET WHEEL	333	OIL PAN
74	GUIDE PIPE FOR 73	167	TIMING GEAR UPPER	246	SET SCREW FOR 246	334	OILER
75	NEEDLE PLATE	168	SET SCREW FOR 167	247	SET SCREW FOR 246	335	BOBBIN WINDER
76	SET SCREW FOR 75	169	SET SCREW FOR 167	248	SET SCREW FOR 246	336	DRIVER LARGE
77	PRESSER BAR BUSHING UPPER	170	STOP RING FOR 173	249	SET SCREW FOR 250	337	KNEE LIFTER COMPLETE
78	PRESSER BAR BUSHING LOWER	171	ROCK SCREW FOR 175	250	FEED BAR BELL CRANK	338	BELT COVER COMPLETE
79	SET SCREW FOR 77 & 78	172	SET SCREW FOR 174	252	SET SCREW FOR 267	339	INSTRUCTION BOOKLET
80	PRESSER FOOT	173	TIMING GEAR LOWER	253	HINGE SCREW FOR 208	340	SPOOL HOLDER
81	SET SCREW FOR 80	174	SAFETY CLUTCH			341	HOOK SADDLE
						342	HOOK SADDLE COVER
						343	TAKE UP LEVER
						344	GUARD FOR TAKE UP LEVER
						345	OPENER
						346	OPENER BRACKET
						347	OPENER ROD
						348	HOOK SHAFT UPPER BUSHING
						349	HOOK SHAFT LOWER BUSHING
						350	ROTATING HOOK ASSEMBLY
						351	BOBBIN
						352	MODEL PLATE (AD-331L)
						353	MODEL PLATE (AD-332L)
						377	CORNER RUBBER
						378	BED HINGE
						379	HINGE RUBBER

LP-TYPE

(LP = LARGE BOBBIN & PIPING)

355	LAPPER BASE
356	LAPPER BASE KNOB
357	LAPPER FEEDING BLOCK
358	HINGE SCREW FOR 357
359	HINGE SCREW FOR 355
360	SPRING FOR 359
361	LAPPER COMPLETE 25M/M
362	SET SCREW FOR 361
363	FLAT WASHER FOR 362
364	LAPPER DRIVING ARM
365	SET SCREW FOR 364
366	LAPPER DRIVING ARM BRACKET
367	HINGE SCREW FOR 366
368	SET SCREW FOR 366
369	LAPPER DRIVING FORK
370	HINGE PIN FOR 369
371	STOP RING FOR 370
372	SET SCREW FOR 370
373	MODEL PLATE (AD-331LP)
374	MODEL PLATE (AD-332LP)
375	WALKING FOOT COMPLETE
376	PRESSER FOOT